


## **SAMPLE PERFORATIONS:**

Model PR-10, Model 206, Model 103 PAID



Model PR-10, Model 206 & Model 103 VOID



Model 206 & Model 103 CNCLD

••	•	•		•	••
•	•	۰	•	•	• •
•	• 7	٠	•	•	• •
•	• •	۲	•	•	• •
• •	٠	•	••		••

Model 206 & Model 103 PAGADO

•	•	•			•	•		•	•	•.	•	•
•	•		•		•	•		• •	•		•	
•			٠	۲	۰	•	٠	٠	•	•	•	•

※ All the above machines are FIXED LETTERS and not changeable letters.




## **SAMPLE PERFORATION:**

Model 206 & Model 103 CANCELADO or CANCELLED




Model 605, Model 10-605 & Model 112-605 Sizes available for perforations of Letters/Marks/Symbols





PAID in Indonesian

Symbol & Letters





% All the above machines are FIXED LETTERS and not changeable letters.



## **SAMPLE PERFORATION:**

Model 705, Model 10-705 & Model 112-705 Sizes available for perforations of Letters/Marks/Symbols





% All the above machines are FIXED LETTERS and not changeable letters.



## **SAMPLE PERFORATION:**

Model 207, Model 208, Model 10-905, Model 10-905L, Model 112-905 & Model 112-905L 8-digits dating/numbering

Each digit has from 0 to 9, " " (blank) & "+" mark. Therefore you can perforate date & number by the same machine.


10-digits dating/numbering

Each digit has from 0 to 9, " " (blank) & "+" mark. Therefore you can perforate date & number by the same machine.

PAID & DATE (8-digits)

% 1st line: Fixed Letters "PAID"
2nd line: 8-digits dating/numbering

Model 208N, Model 10N, Model 194-911 From 0000001 to 9999999



Х

You can perforate automatically consecutive number from 0000001 to 9999999 and same number.